Angekïs®

Cleartalk ASP04D-2
Wireless Daisy Chain
Speakerphone

Overview

This is a 2.4 GHz wireless communications system comprised of 2 speakerphone devices which have been daisy chained together and work through a USB dongle. Each device has an omnidirectional microphone, a speaker, and a battery, and these features enable them to easily cover a medium sized conference room. The device is plug and play and does not require any extra drivers or software. It is professional grade equipment, suitable for all kinds of video and audio conferencing needs.

Component

LED Indicator
1. Blue triangular Indicator: normal working status
2. Blue bottom right indicator: loudspeaker mute
3. Blue bottom left indicator: microphone mute
4. Blinking blue bottom left indicator: volume adjustment
5. Blinking orange bottom left indicator: low power

Packing list

Speakerphone
（2 pcs）

1.5mUSB cable
（2 pcs）

5V1A power adapter
（2 pcs）

Wireless adapter

Quick start guide

Warranty card

Installation

camera

TV or conference tablet

PC

Speakerphone

USB power

USB wireless adapter

Compatible with Windows，Mac and Android systems

Note: do not place the devices within 10cm of the 2.4GHz wireless adapter.At
ranges less than 10cm interference may cause abnormal sound pickup.

3.5mm audio application
installation

Charging installation

Basic Functionality

1 . Internet conference call
After successful connection, open your computer's instant communication software for
real time calling.

2. Volume adjustment
Adjust to the appropriate volume with "vol+" and "vol-" on the device.

3. Microphone pickup and mute
The default microphone status is ON and the microphone can be turned OFF
by pressing the microphone mute button.

4. Speaker play and mute
The default speaker status is power ON and the speaker can be
turned OFF with the loudspeaker mute button.

5. External audio equipment
The devices can be used as external loudspeakers for computers to play
corresponding audio.

6. LED indicator
The LED status indicator displays the working status of the device in real time.

7. Support headphones to play audio
By connecting the 3.5mm audio interface and turning off loudspeaker, the
headphones can be used for private communication.

8. 2.4 GHz wireless communication
Connection between the devices and the computer runs through the 2.4 GHz adapter.

Operation

The whole operation:
1. Connect wireless adapter to the computer or laptop USB port.
2. Turn on the devices.
3. Open communications software on your computer and enjoy.

Speaker operation:
1. Turn on/off
Long press ⏻ key to start, and again long press to shutdown.
2. Loudspeaker mute
Press 🔊 to turn off the speaker. Press 🔇 again to turn on.
3. Microphone mute
Press 🎤 to turn off the microphone. Press 🎤 again to turn on it.
4. Vol-
Press 🔉 gradually to lower speaker volume or long press 🔉 to lower speaker volume continuously.
5.Vol+
Press 🔊 gradually to increase speaker volume or long press 🔊 to increase the speaker volume continuously.
6.Charging
Connect power adapter to to 220v outlet and USB port to device.
7. Private audio output
Connect 3.5 mm headphone to 3.5mm interface, press the loudspeaker button, so that it can output audio separately.

2.4 GHz wireless adapter operation:
Connect wireless adapter to computer or laptop USB port. It supports Windows XP and newer, Mac OS, Linux, and others with plug and play functionality, no need install drivers.

Note:
1. The equipment is compatible with other speakers simultaneously.
2. After successful connection, if the input and output of the audio equipment on the computer control panel are not all "Cleartalk ASP04D-2", this may result in abnormal audio from the device.
3. Please do not place the device within 10cm of the 2.4GHz wireless adapter. When it is less than 10cm away, abnormalities may occur.

2.4 GHz wireless digital conference speakerphone system.
2 battery powered Cleartalk Wireless ASP-04 units daisy chained together to cover large rooms.
Professional. Versatile. Powerful.