

## Basic Features

### 1. Internet conference call:

After successful connection, open your computer's communications software for real time calling

### 2. Volume adjustment

Adjust to appropriate volume by "vol+" and "vol-" on the host

### 3. Microphone mute button

Mute the microphone on and off via the microphone mute button

### 4. Speaker mute button.

Mute the speaker on and off via the speaker mute button

### 5. External audio equipment

The ASP-04 can be used as an external loudspeaker device for computers to play corresponding audio

### 6- LED indicator

The LED status indicator displays the working status of the host in real time

### 7- Support headphones to play audio

Connecting to the 3.5mm audio interface will turn off the loudspeaker and sound will come from headphones only.

### 8.2.4 G wireless communication

Both connection between computer and speaker is by 2.4 GHz wireless adapter

## Attention for best performance

1. To obtain the best performance, please read the operating instructions carefully and keep it for future reference.
2. Please install the product in a dry place with good ventilation, avoiding direct sunlight, vibration, wet and cold, and keep away from heat sources and dust.
3. Please keep the product far from motor, transformer, and other electronic equipment to avoid disturbances.
4. The product shall not be exposed to large temperature variations or high humidity, in order to prevent condensation occurring inside.
5. The following objects shall never put on the product:
  - 1) Hazardous components, since they will cause damage and discoloration to the product surface
  - 2) Burning objects (such as candles), since they may cause fire, damage to the product, and personal injury
  - 3) Containers holding liquid, since liquid will cause electric shock to the user and damage to the product should they spill.
6. For heat dissipation, never cover the product with the objects like paper, table cloth, or curtains. The rise of the inner temperature of the product may cause fire, damage to the product and personal injury.
7. Never install the product in a place where external objects may drop or liquid may splash.
8. When unplugging the USB cable, please hold the plug part and never pull the cable.
9. Keep hands dry when using USB cables, as water may cause fire, electric shock, damage, short circuit and open circuit.
10. Never loosen screws of the product at will, which may cause poor sealing and influence the quality and effect.
11. Never try to repair the product by yourself, if you have any problems, please contact your dealer.

# Angekis®

## User Manual


### ASP-04 Wireless Speakerphone

Please read the user manual before using the product and keep it for future reference.

## Product Overview

Thank you for choosing Angekis. The ASP-04 is a speakerphone based on 2.4GHz wireless communications and wireless charging technologies. With intelligent audio processing, echo cancellation, and other smart and intuitive features, this device is an excellent solution for your audio conferencing needs. With a 3 meter, 360 degree pickup range, it is suitable for small to medium sized rooms.


## Component Instruction



### LED Indicator


1. Blue triangular Indicator: normal working status
2. Blue bottom right indicator: loudspeaker mute
3. Blue bottom left indicator: microphone mute
4. Blinking blue bottom left indicator: volume adjustment
5. Blinking orange bottom left indicator: low power

## Packing list



## Assembling


### Application installation



## 3.5mm audio application installation



## Wireless charging installation



## Start up

### The whole operation:

1. Connect wireless adapter to computer or laptop USB port
2. Turn on wireless speaker power
3. Open instant messaging software on computer and then you can enjoy a high quality audio meeting. Be sure to select the audio device for microphone and speaker for the ASP-04.

### Speaker operation:

1. Turn on/off  
Long press key to start, and again long press shutdown.
  2. Loudspeaker mute  
Press to turn off the speaker. Press again to turn off the speaker.
  3. Microphone mute  
Press to turn off the microphone. Press cancel to turn off the speaker again.
  4. Vol-  
Press gradually to lower speaker volume or long press to lower speaker volume continuously.
  5. Vol+  
Press gradually to increase speaker volume or long press to increase the speaker volume continuously.
  6. Charging  
Connect power adapter to 220v and USB port to main device
  7. Audio alone output  
Connect 3.5 mm headphone to 3.5mm interface, press the loudspeaker button, so that it can output audio separately.
- Wireless speaker operation:

### 2.4 G wireless adapter operation:

Connect wireless adapter to computer or laptop USB port. It supports Windows 8 / Windows 7 / Windows 10 / Windows XP and other systems, plug and play, no need to install extra drivers

### Note:

1. The equipment cannot be compatible with other speakers at the same time
2. Ensure the 2.4ghz wireless adaptor is at least 20cm away from the speaker mic when in use.